



Air Conditioning / Heating
(561) 482-7495
(561) 368 0028 Fax



Air Conditioning Troubleshooting Guide

- My air conditioner is blowing hot air
 - Reset your circuit breaker
 - Check FPL on call box is applicable
 - Check humidistat for proper setting
 - Check thermostat setting
 - Check filter
 - Check outdoor unit circuit breaker
- My air conditioner does not have any power
 - Reset your circuit breaker
 - Check FPL on call box if applicable
 - Check thermostat setting
 - Check humidistat for proper setting
 - Check air handler breaker
 - Check overflow safety float switch
- My thermostat is blank or blinking
 - Replace the thermostat batteries
- There is no power to the air handler (indoor unit)
 - Check overflow safety float switch
- My air conditioner is cutting on and off continuously
 - Check the drain pan for water. If there is standing water in the drain pan, your air conditioner may be turning off intentionally after triggering the float switch as a preventative measure.
- There is water leaking from my air conditioner
 - Check to ensure that the condensation drain is not backed up
 - Check for a dirty air filter and replace if needed
 - Unit needs servicing
- My air conditioner has ice on it
 - Check for a dirty air filter and replace if needed
 - Make sure that your thermostat is not set under 70°
 - Check to ensure that the grille for your air return is not blocked
 - Call for service. Your air conditioner may be low on Freon
- My air conditioner is unusually noisy
 - Check for a dirty air filter and replace if needed
 - Call for service. The air handler blower wheel may be out of calibration
- My air conditioner smells like it is burning
 - Turn off your air conditioner and call for service
- My air conditioner has an unusual odor (non-burning)
 - Check for a dirty air filter and replace is necessary
 - Add UV Light air purifier (visit 'Solutions→Air Purification' pages www.romeaire.com/solutions-2/air-purification for more information